



External Flex Between Components




Internal Flex
On Components

Remember: Never flex or bend at an LED chip, IC, resistor or any other components above the recommended angle since that will eventually weaken the solder and damage your LED Strip, voiding the warranty.




Internal Flex Between Components



External Flex On Components







Note: For horizontal right angles or any other horizontal angles use couplers or solder jumper wires between the LED Strip segments.



Note: When flexing between components you can solder jumper wires to decrease the flex point diameter and allow for a sharper bend.