




WIRING APPLICATION DIAGRAM 1


DATA CONNECTION TO SOFTWARE

POWER CONNECTION (MAY VARY)










MADRIX USB REQUIRED TO RUN SOFTWARE



WIRING OPTIONS ARE NOT LIMITED TO THE ONES DEPICTED IN THIS DIAGRAM. FOR A FULL LIST OF OPTIONS PLEASE VISIT MADRIX NEBULA QUICK START GUIDE


OPTION 1

V102622 1-2 WIRING APPLICATION



WIRING APPLICATION DIAGRAM 2

DATA CONNECTION TO SOFTWARE



OPTION 2

WIRING OPTIONS ARE NOT LIMITED TO THE ONES DEPICTED IN THIS DIAGRAM. FOR A FULL LIST OF OPTIONS PLEASE VISIT MADRIX NEBULA QUICK START GUIDE

V102622 2-2 WIRING APPLICATION